

# ApogeeFirewire : Windows XP SP2 Driver v 2.11

---



The Windows XP driver version 2.11 has been tested with XP versions SP1 and SP2. Please be aware of the following considerations when installing the driver.

- DO NOT CONNECT the X-Firewire equipped host interface to the computer before launching the driver's setup.exe installation program.
- Connect ALL the X-Firewire equipped host interfaces when instructed to do so by the setup.exe installation program. For an audio application to "see" an X-Firewire equipped host interface, the interface must be connected at the specified moment during the driver installation procedure.
- If you change any aspect of the X-Firewire equipped hardware, such as the serial number of the X-Firewire cards used or the number of interfaces used, it's necessary to re-install the driver.
- If your computer is equipped with FW 800 connections, you must connect the X-Firewire card to the computer using a FW800 cable. If you use a FW400 cable, the X-Firewire card won't be recognized by the computer and the driver installation procedure won't complete correctly.
- If your computer is equipped with FW 800 connections, you will need to perform a Microsoft "hotfix" to resolve a Windows issue concerning FW 800 connections. You can find more details here:

<http://support.microsoft.com/kb/885222>

**The Apogee Technical Support Team**  
**service@apogeedigital.com**